


## MODEL RT-1 TRIMMER 120 VOLTS



ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
1	77083	Lower Housing	1
2	77026	Upper Housing	1
3		Beauty Cover	
3a	77027	Beauty Cover (Satin Chrome)	1
3b	77092	Beauty Cover (Inferno Red)	1
3c	77097	Beauty Cover (Black Flame)	1
3d	77098	Beauty Cover (Pink Pattern)	1
4	19124	Front Housing Screw	2
5	32580	Rear Housing Screw	2
6	77024	Switch Actuator	1
7	77127	Motor Sled Assembly	1
8	77129	Cord	1
9	77011	Hanger Hook	1
	1		

ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D

## IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use, If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S., attach a letter to outside of package explaining difficulty.

Form #

77131

Revision:

Date: 8/26/11