


SERVICE PARTS LIST MODEL DBLC-2 DOM ANIMAL CLIPPER 120 VOLT



ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
1	79048	Housing Screw	2
2	201258	Lower Housing	1
3	79029	Motor Screw	2
4	79036	Motor Assembly	1
5	27864	Hinge Screw	2
6	63897	Hinge Assembly	1
7	64535	Lock Keeper	1
8	79025	Battery Pack	1
9	201381	Middle Housing	1
10	20658	Blade Drive Assembly	1
11	15766	Blade Drive Screw	2
12	201053	Drive Cap	1
13	201899	Upper Housing Assembly (Upper Housing, Lens, Speed Actuator Keeper, Speed Actuator Button, Speed Switch Return Band)	1
14	202388	PCB Assembly (PCB, Switch Actuator, Screw)	1
15	201908	Insulator	1
16	201248	Housing Screw	2
17	201246	Adaptor	1
18	79073	Stand	1

NO.	NO.	DESCRIPTION	REQ'D
	I		

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use, If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S., attach a letter to outside of package explaining difficulty.

FORM 201872 Rev-K 01/09/20 ECN #24504 SERVICE CENTER